

# DWC-XSTD05MFCx | 5MP turret IP camera with Ai, x= storage size

DW





Mounting Star Wrench 1 1 (T10) Hexagonal

Waterproof Cap and Rubber Rings (Black: Ø0.15" (ø4mm), White: Ø0.19"	
_(ø5mm))	
NOTE: Download all your support materials and tools in one place  1. Go to: http://www.digital-watchdog.com/resources  2. Search your product by entering the part number in the 'Search by Product' search bar. Results for applicable part numbers will populate automatically based on the part number you enter.  3. Click 'Search'. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.	
<b>Attention:</b> This document is intended to serve as a quick reference for the initial set-up. It is recommer that the user read the entire instruction manual for complete and proper installation and usage.	ded

STEP 1 - PREPARING TO MOUNT THE CAMERA 1. Install the Dessicant Pack (moisture absorber): • Remove the Dessicant Pack from its shipping packaging.

ensure no cables are caught or disconnected.

Template

Open the camera's control panel on the side of the camera using the star wrench included with the camera. · Remove the Dessicant Pack used for shipping and place the new Dessicant Pack in the location shown in the illustration below.

Close the camera control panel tightly. When closing the control panel,



button for five (5) seconds to initiate a camera-wide reset of all the settings,

STEP 2 - POWERING THE CAMERA

Pass the wires through and make all necessary connections.

including network settings.

Use a PoE Injector (required. Sold

power to the camera using a single

**Power information** 

Power requirements


Power consumption Maximum distance

Connector

separately) to connect data and

**®** 

NOTE: The camera will generate enough heat to dry moisture during operation. In cases where the camera can experience a moisture issue, keep the moisture absorber in the camera. The moisture absorber has an approximately 6-month life cycle.



0

0

RECORDER

SEAL TAPE

Use a non-PoE Switch to connect

data using an Ethernet cable and

use a power adapter to power the

DC12V, PoE IEEE 802.3at Class4 (Adapter not included)


CAMERA

Ethernet cable. camera. OR 


328' (100m)

b

RJ45



12V DC: 12W, 1A, PoE: 15.8W, 330mA




Rotation 360°

smudges left from the installation process.

Panning 360°

NOTE: When setting up the camera for the first time, use the CALIBRATE button on the camera's web GUI to auto calibrate the camera's lens before operation. 3. Remove the protective film from the lens cover. Softly wipe the lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or

Tilting 87°



٨

Protective film

DIN (+)

DIN (-)

DOUT (-)

DOUT (+)

Audio In

Password must have at least eight (8) characters and at least four (4) combinations of uppercase and lowercase letters, numbers and special characters. Passwords cannot

Download and install the DW IP Finder from the DW website at:

Open the DW IP Finder and click 'Scan Devices' to find the camera

WHITE

YELLOW

SKY BLUE

GRAY + DOT

🌀 Alarm In

4 Audio Out

Use the diagram below to connect power, network and external devices such

as audio input and output, alarm and sensors to the camera.

Mounting template

# 3. A password must be set when connecting to the camera for the first a. Check the box next to the camera. b. Click "Bulk Password Assign" on the left. c. Enter admin/admin for the current username and password. Enter a new username and

on the network.

Power

STEP 5 - DW® IP FINDER™

password to the right.

contain the user ID.

STEP 6 - WEB VIEWER

WODIGITAL WATCHDOG

d. Click "change" to apply all changes.

Find the camera using the DW IP Finder.

http://192.168.10.159/ - IP Camera - Internet Explorer

Password Retype Password

3. Press the 'View Camera Website'.

Finder

2. Double-click on the camera's view in the results table.

http://www.digital-watchdog.com

STEP 4 - CABLING

4. Enter the camera's username and password you setup in the DW IP

If you did not setup a new username and password, a message will direct you to setup a new password for the camera to view the video.

Change admin's password

The GUI display may differ by camera models.



NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

Specifications and pricing are subject to change without notice. Rev: 11/24

Tel: +1 (866) 446-3595 / (813) 888-9555 Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

Patents listed at patentlist.accessadvance.com. digital-watchdog.com Copyright © Digital Watchdog. All rights reserved.

Password Hint [ Type the Password ] Password requirement: minimum 8 characters with at least three combinations of uppercase letters, lowercase letters, numbers and special characters Acceptable special characters are;  $\sim$  `! \$ ^ () \_ - | {} []; . ? /

This products is covered by one or more claims of the HEVC